



CP66 Luminaire




036AL Power Supply



WIRING


CP66-WPS




Power Supply Options

PWR-CLN-240-48-036AL	240W 230VAC mains voltage (110 – 305VAC / 154 – 431VDC)
PWR-CLN-320-48-036AL	320W 230VAC mains voltage (110 – 305VAC / 154 – 431VDC)
PWR-CLN-240-48-WVR-036AL	240W 415VAC mains voltage (180 – 528VAC / 254 – 747VDC)

Fixed Plant Bracket
MBR-CP66-FPB




Mobile Plant Bracket (Optional)
MBR-CP66-MPB



MOUNTING BRACKET INSTALLATION


Step 1

Install arm locks onto protruding studs on both sides of the housing as shown below.




Step 2

Apply necessary force to open the bracket in order to fit over the properly positioned arm locks.



Step 3

Align perforated slots in mounting bracket against corresponding notches in the arm locks, then tighten the nut. Ensure that all the perforated slots sit firmly on the notches after tightening up the nuts. Recommended tightening torque is 40Nm.



Please use Loctite® 243™ retaining compound (not included) to secure the dome nut.

IMPORTANT: Ensure that all perforated slots sit firmly on the notches after tightening up the dome nuts.

