#### CP22 Luminaire w/ Standard Bracket



## MOUNTING BRACKET INSTALLATION

## Step 1

Mount light fitting to appropriate location.



## Step 2

To adjust the mounting angle, unscrew bolt and loosen dome nut.



#### Step 4

Use Loctite® 243<sup>™</sup> retaining compound (not included) to secure the dome nut. Screw in and tighten bolts on both sides.





### Step 3

Adjust the angle of the light fitting, and line up bracket holes to either the top or bottom mounting holes.



## CONFIGURATION

# ELV

Extra Low Voltage







