




ISLE BAY™ LUMINAIRE



⚠ ATTENTION:
Unit must not be operated with the optical face blocked or obstructed.

The ISLE BAY™ has a high intensity light output designed for warehouse applications and other clean environments. It is of critical importance that the polycarbonate optical face of the luminaire is regularly cleaned to maintain optimal performance.

Failure to keep the optical face clean may result in decreased light output and luminaire damage. Any damage sustained by the luminaire as a result of a dirty or blocked optical face is not covered under warranty.

INSTALLATION INSTRUCTIONS

Step 1

Align and suspend the ISLE BAY™ so the bracket is parallel to the aisles. Once suspended, connect the cable.

