




# ARIA X RGBW INSTALLATION INSTRUCTIONS




#### PROFILE DIMENSIONS





#### INCLUDED

**Box Contents** 



- 600mm Fitting
- Mounting Brackets (Integral)

+ Run Box

100mm



- Allen Key
- Cable Plastic Caps
- Cable Kits

	LxWxH	
CONTENTS	DIMENSIONS	WEIGHT
1 x <b>06</b> Luminaire	582 x 191 x 121mm	4.2kg
2 x <b>06</b> Luminaire	582 x 191 x 121mm	8.4kg


. ... ..

# **A** ATTENTION

- Please observe / follow the instructions methodically.
- Please ensure the units are handled with extreme care.
- · Do not remove product from packaging prematurely. Only remove from packaging when ready for installation.
- Failure to observe installation instructions and handling will void warranty of the product.
- Fittings must be installed by a licensed electrician.
- Before installing, make sure the power supply is switched off or mains cable is disconnected.


# ■ INSTALLATION LIMITS @ 230VAC


Maximum 24 x 600mm fittings per individual run.



#### ■ INSTALLATION LIMITS @ 120VAC


Maximum 12 x 600mm fittings per individual run.








#### WIRING CONFIGURATION



#### **DATA** Loom Wiring







#### MAINS Loom Wiring











# CONNECTION

Before installation begins, please ensure that you understand the fitting layout as per luminaire schedule.












# DIMENSIONS



#### Bracket Bottom View




#### ROTATION WITH MOUNTING BRACKETS







DIMENSIONS WITH GLARE SHIELD



#### Bracket Bottom View




ROTATION WITH MOUNTING BRACKETS + GLARE SHIELD



# ADJUSTING THE MOUNTING BRACKET


# • STEP 1

Loosen **Screws A** and **B** counter clockwise to allow for rotation of the luminaire.




# • STEP 2


Rotate the luminaire to your desired angle.



#### • STEP 3

Tighten **Screws A** and **B** clockwise to lock into position (4 - 5Nm).





# SAFETY LANYARD

Please utilize provisioned apertures if safety lanyards are required in the installation.



