
COOLON MACHINE LIGHT INDUSTRIAL LED MANUAL EDITION 0.4




INSTALLATION INSTRUCTIONS

Step 1

Remove the 4x socket head screws to separate the base and the main assembly.

Step 2

Secure base to the mounting surface.



Step 3

Place main assembly onto the base and secure using 4x socket head screws from Step 1.

Step 4

Your Machine Light is now ready to be connected!

